



Flame Humidifier User Manual



- Adjustable full-color flame effect
- Wood grain decorative panel
- Temperature/humidity/time display function
- Material added with silver ion antibacterial
- Optional UVC ultraviolet sterilization

Product introduction



Packing List

Humidifier x1
24v Power Supply x1
Aromatherapy Box (optional)
10ml Aromatherapy Oil (optional)

Button Instructions

Power Button:

Short press to toggle between modes:
H1 High Mist, H2 Medium Mist,
H3 Low Mist, OFF to turn off.

Display Button:


- 1.Short press to switch screen display mode (Time-Humidity-Turn Off Screen).
- 2.Long press to set the time. During this, a short press on the light button increases the value, while a short press on the power button decreases it. Short press the display button to toggle/save settings.

Light Button:

Short press to switch light colors (Custom Color - Red - Blue - Nightlight White - Gradient Color).

Long press until the screen displays "clr" to start setting a custom color. Wait for the color wheel to rotate to the desired color, then release the button.

User Instructions



- 1.After opening the top cover, pour purified water into the humidifier, ensuring the water level does not exceed the air outlet.
- 2.Add 2-3 drops of water-soluble essential oil to the aromatherapy box (for a more pronounced aroma, you can also directly drop the aromatherapy oil into the water).

Setting the Time: Press and hold the display button to enter the time setting mode. In this mode, the light button can be used as a plus button to change the hours. A short press on the display button switches to setting the minutes, and another short press saves and exits.

Customizing Color: Holding down the light button will make the colors cycle automatically (the screen will display "clr") until you release it, selecting your preferred color.

Precautions

Do not disassemble the product on your own. If damage occurs, the warranty might be voided. Ensure the water level does not exceed the air outlet; otherwise, mist might not be produced, or the circuit board could be damaged. When emptying waste water, pour from the side and back of the humidifier. When humidity is high, it's normal for water vapor to deposit around the humidifier when set to high mist mode. It's recommended to use purified or distilled water.

Product Name: Clocteck Flame Humidifier
Rated Input Voltage: 24v
Rated Input Current: 500ma
Water Tank Capacity: 720ml
Maximum Usage Time: 48h
Maximum Humidification: 120ml/h
Product Dimensions: 280*85*95mm
Standard: ISO 22196:2007